

Owner's Manual

Vanshower – rear tent Volkswagen T5

Thank you for buying our VanShower- Set.

You will have a long-lasting and practical item for your camping trip, if the tent is mounted according to this instruction. Please read this instruction carefully before you start mounting the tent.

Mounting the Velcros

It is very important, to clean the surfaces where the velcros will be attached carefully - especially the plastic parts of the panelling. Use a light plastic cleaner first. Then use the enclosed cleaning pads. Temperatures need to be 15°C or higher for fixing the velcros. Give your velcros a 24 hour rest before attaching the VanShower rear tent the first time. The tent can also be mounted instantly, but for a long-lasting adhesive power we recommend waiting for 24 hours. **The velcros only need to be mounted once and will stay on the car.**

Compare illustrations on pages 1 and 2, for finding the right positions.

1. 2 narrow velcros (3cm) on either side, directly beneath the lock.
2. 2 wide velcros (38 cm) left and right of the tailgate lock. For vehicles with panelling (Multivan), shorten the right Velcro and attach it directly next to the panelling button.
3. 2 wide straps (10 cm), one on either side towards the corner of the panelling.
4. 2 narrow velcros (20 cm) left and right.
5. 2 narrow velcros (10 cm) left and right.
6. 2 narrow velcros (10 cm) directly outside the tailgate hinges.
7. 2 narrow velcros (15 cm) on the inside panelling of the rear lights.
8. 2 narrow velcros (15 cm) directly onto the metal sheet below the button, as illustrated on page 2.

Mounting the VanShower rear tent

1. Hang the S-hook into the tailgate lock. Make sure it points to the outside (photo page 2). Now hold the hook and close the lock with your other hand. The hook is now fixed.
2. Adjust the two pipe clamp hooks to the rubber plugs, hooks facing outside (compare photo page 2).
3. Now attach the VanShower tent by placing the eyelet into the middle hook. Attach the velcros on both sides along the tailgate.
4. Fix the tent to the two pipe clamp hooks on either side.
5. Place the velcro rings around both gas struts and close them.
6. Fix the lower velcros next to and underneath the back lights.
7. Fix all ladder rubber bands to the ground using pegs (in case the soil is too hard, simply place heavy objects on the rubber bands).

For dismounting the VanShower tent, just proceed in the opposite order.

To get the hook out of the tailgate lock, pull the tailgate downwards a bit and then pull at the door lock handle.

Scope of delivery

- | | | |
|---------------------|----------------------|------------------------|
| - 1 rear tent | - 2 pipe clamp hooks | - 1 tent peg extractor |
| - 1 shower curtain | - 1 S-hook | - 2 cleaning pads |
| - 16 velcros, black | - 5 pegs | - 1 transport bag |

Should you need more information, please send us an e-mail (info@vanshower.de) or visit us on www.vanshower.de