

Installation guide

Packing bags

-

ID. Buzz



Take notice of the correct side: the VanEssa logo shows towards the boot (pic. 1).

Tip:
In order to avoid moisture behind the bags, take them out from time to time and let them dry during the day.





First press the packing bag into the window at the top, then at the bottom, so that the bags are firmly positioned on the bottom of the trim panel (pic. 2 + 3).



If the bag is a little too loose, attach the PE-strip to the underside of the packing bag using the Velcro and then insert it back into the window (pic. 4).



5a.



5b.



5c.

Important objects such as the cell phone (pic. 5a), keys (pic. 5b) or sunglasses (pic. 5c) can be deposited at the additional applications.

Für weitere Fragen sind wir gerne für Sie da unter
+49 (0) 8063 / 20 760 - 0 oder info@vanessa-mobilcamping.de

VanEssa mobilcamping | Lauser Strasse 27 | 83620 Grosshöhenrain | Deutschland
Tel. +49 (0) 8063/20 760-0 | info@vanessa-mobilcamping.de